

Replace with Cuff and Adapter indicated below:

		Replace with Cuff and Adapter indicated below:							
		Cuffs				Adapters			
						For use with DS44 & DS45 Gauges		For use with DS48 Gauge	
Old Part Number *		REUSE-09	REUSE-10	REUSE-11	REUSE-12	1-DSAL	1-DSAS	1-SRCL	1-SRCS
D44-DUR09		◆					◆		
D44-DUR10			◆				◆		
D44-DUR11				◆		◆			
D44-DUR12					◆	◆			
DS45-DUR09		◆					◆		◆
DS45-DUR09F		◆					◆		◆
DS45-DUR10			◆				◆		◆
DS45-DUR10F			◆				◆		◆
DS45-DUR11				◆		◆		◆	
DS45-DUR11F				◆		◆		◆	
DS45-DUR12					◆	◆		◆	
DS45-DUR12F					◆	◆		◆	

1-DSAL	Adapter (for DS44 and DS45 Aneroid Gauge), Tubing, Large Premium Bulb and Valve
1-DSAS	Adapter (for DS44 and DS45 Aneroid Gauge), Tubing, Small Premium Bulb and Valve
1-SRCL	Adapter (for DS48 Aneroid Gauge), Tubing, Large Premium Bulb and Valve
1-SRCS	Adapter (for DS48 Aneroid Gauge), Tubing, Small Premium Bulb and Valve

*** Note: Part Numbers ending in 'F' included an adapter with tubing and a Premium Bulb and Valve. All other part numbers included an adapter and tubing only - no bulb and valve. The "No Bulb and Valve" option is no longer available. All adapters come with bulb and valve as described above.**

The DS45-DURXX and DS45-DURXXF cuffs included BOTH DS44/45 and DS48 adapters. Determine which gauge the customer is using to select the correct adapter.